



TPMS



Gussin TPMS Relearn Procedure A4038

Sensor Relearn Procedure without a scan tool

- OBDDongle is required
- Confirm TPMS sensors are properly installed
- Adjust tire pressures to placard value
- Hold TPMS Tester on left front tire sidewall next to the valve stem
- Repeat for LR/RR/RF tires
- Apply OBDDongle to DLC
- Turn ignition to ON
- Press OK on TPMS Tester to transfer data to ECU
- Disconnect OBDDongle from DLC
- Turn ignition to OFF then ON
- Wait for 5 minutes
- Drive at 12mph for up to 20 minutes

Sensor Relearn Procedure with a scan tool

- OBDDongle is not required
- Confirm TPMS sensors are properly installed
- Adjust tire pressures to placard value
- Activate sensors with TPMS Tester
- Drive for up to 10 minutes