



**TPMS**



## **Gussin TPMS Relearn Procedure A0124**

### **Sensor Relearn Procedure without a scan tool**

1. OBD II dongle is required
2. Confirm TPMS sensors are properly installed
3. Adjust tire pressures to placard value
4. Hold TPMS Tester on left front tire sidewall next to the valve stem
5. Repeat for LR/RR/RF tires
6. Apply OBD dongle to DLC
7. Turn ignition to ON
8. Press OK on TPMS Tester to transfer data to ECU
9. Disconnect OBD dongle from DLC
10. Turn ignition to OFF then start the engine
11. Drive for at least 5 minutes at 28 mph

### **Sensor Relearn Procedure with a scan tool**

1. OBD II dongle is not required
  2. Confirm TPMS sensors are properly installed
  3. Adjust tire pressures to placard value
  4. Apply parking brake
  5. Turn ignition ON/RUN
  6. Use the five-way DIC control button on the right side of the steering wheel until Tire Pressure is displayed
  7. Push and hold the Select button down in the middle of the DIC control
  8. Horn chirps 2x DIC displays TIRE LEARNING ACTIVE
  9. Use tool to active LF sensor
  10. Single horn sounds
  11. Repeat for RF/RR/LR
  12. Horn chirps 2x for relearn complete
- Tip: Lowering driver's side window may help to complete this process on larger vehicles